



## Quick Start Guide

- 1 **Download and install the Nightingale app from your mobile app store.**

For Apple users, go to the Apple App Store. For Android users, go to Google Play.


- 2 **Plug one Nightingale unit into an outlet in your room.**

Plug the other unit into a different outlet in this room. For better acoustic coverage, choose outlets on opposite walls. (Please do not plug units into each other.)

- 3 **Launch the Nightingale app to configure your Nightingale units.**

You will need access to an active email account, to register the units. Once they are configured, you can control them through this app or through any supported browser at: [www.controlnightingale.com](http://www.controlnightingale.com)

# Technical Specifications



## Physical Dimensions (each):

Height 4.3", Width 2.7", Depth 1.7"  
(Depth is 1" when it is plugged in)

**Weight:** 5.5 oz.

**Voltage (pass-through):** 110 V

**Amperage (pass-through):** 15 A

**Number of Speakers (each):** 2

## Masking Blanket Frequency Range:

500 Hz - 4 kHz @ 30 - 50 dB (SPL)

## Sound Pressure Range:

0 - 60 dB (SPL)

## Optimal Sound Pressure:

43 dB (SPL)

## Radios:

(1) Wi-Fi 802.3 (2.485 GHz)

(1) Bluetooth LE 802.2 (2.485 GHz)

## Communication Security:

AES

**Coverage Area (per pair):** 300 sq. ft.

**Number of Sound Blankets:** 15

## Nightlight Colors:

White, red, yellow, blue, green

## Patents & Trademarks:

U.S. Provisional Application  
No. 62/219,536 (9/16/15)

U.S. Non-Provisional Application  
No. 14/985,879 (12/31/15)

International Patent Application  
No. PCT/US2015/068283

## Warranty:

1-year limited warranty



For more information, including safety and FCC guidelines,  
please refer to the Nightingale website: [meetnightingale.com](http://meetnightingale.com)